

14181-40200	GASKET EXHAUST FRANGE	RM100 N, T, X
09384-28001	KICK STARTER SPRING	RM125 D, E, F, G, N, T, X DS80 F, G, H, J, K, L, M, N, P JR80 K1, K2, K3, K4, K5, K6
13383-14200	NEEDLE JET	RM250 X RM465 Z
12151-14100	PIN PISTON	RG500 G RG500C H
09280-43002	O-RING	TS250 E, G, H, J, K
09100-06033	BRAKE CAM LEVER BOLT	DR125 F, DR200G, DR750 J, GN125 D-R GN250 F-Y, GS125 D-Y, GV1400G C, H, J
09160-05017	WASHER	A100, DR125, DR200, DR250, DR350, DR650, DR800, GR650, GS125, GS250, GS400, GS425, GS450, GS500, GS550
13370-14300	VALVE ASSY NEEDLE	RM125, RM250, RM465, RM500, TS250
57100-30550	CASE ASSY THROTTLE	TS100, TS125
21431-40D10	PLATE MOVABLE DRIVE	A450
07110-06305	BOLT	GSX750, GSX1100R, GSX600, RF600, RG250, TS50
08113-62000	BEARING, RH	A100, CL50, FA50, FR50, FR80, FS50, GP100, RH50, TS50
11241-46010	GASKET CYLINDER	DS80, JR80
43550-06800	RUBBER FRONT FOOTREST	GSXR1100 G, H, J
23222-36A00	PIECE ARM END	A100, AX100, AX115, RG125, RG80, RNX50 TS50
11482-14100	GASKET	RM125 D, X
44322-27001	FILTER, FUEL	AN125
61421-28000	PLATE CHAIN ADJ.	RB50
31130-31300	TERMINAL SET BRUSH +	GSX750ES D-G
27620-36011	JOINT CHAIN	GP100, TS125 ER N
37110-37172	SWITC ASSYM IGNITION	DR250, GS125
11141-02110	GASKET	AD50, AE50, AG50, AJ50, AP50, AY50 CL50, CS50, TR50, UF50
62226-14520	DUST SEAL UPPER	DR500, DR600, DR750, DR800, GSXR1100, GSXR750, RG500, RM125, RM250, RM500, TS250
13110-45010	PIPE INTAKE	GS1000
11141-14202	CYLINDER GASKET	RM250 X
09492-50022	JET PILOT	DR650 M, N, P, R, S, T
09491-31008	JET MAIN	LS650 M, N, P, G, J, K, L
24762-45000	GASKET	GS1000, GS1100, GS650, GSX1100, GSX750
16448-45000	O-RING	GS1000, GS1100, GS500, GS550, GS850,

02112-06303	SCREW	AD50, AD60, AE50, AG100, AG50, AH100, AJ50, AN125, AN150, AZ50, DR250, DR350, DR800, DS80, FB00, FH50, DRZ125, DR250, DR350, RG50, RH100, RH125, RH250, RH80, RH85, RMX250, TS50, TV50
09285-17001	OIL SEAL	GP100, GP125, PE175, RH100, RM125, TF125, TS100, TS125, RGV250 V
09283-25035	DRIVE SHAFT OIL SEAL	RM125, TS250
09282-10009	OIL SEAL	DL1000, GSXF1200, GSFI250, GSF650, GSXR1000, GXR1100, GSX750, GSX1100, GSX1200, GSX1250F, GSX1300R, GSX1400, GSX650F, GSX750, GV1400
09289-28007	OIL SEAL	AD50, AD60, AE50, AG100, AH100, AH75, AJ50, AV50, FR50, GSF400
23164-05A00	SPRING	RM250, TS250
57110-11B00-291	GRIP THROTTLE	DL1000, GSXF1200, GSFI250, GSF650, GSXR1000, GXR1100, GSX750, GSX1100, GSX1200, GSX1250F, GSX1300R, GSX1400, GSX650F, GSX750, GV1400
02112-05306	SCREW	AD50, AD60, AE50, AG100, AH100, AH75, AJ50, AV50, FR50, GSF400
17431-14303	GASKET WATER PUMP	RM250, TS250
51173-28C00	DUST SEAL	RM250, RM250
54632-01001	BUSH PINION	A100, BX120, CP50, DR125, DR250, FH50, FR50, FR80, FZ50, GP100, GP125, GS125, PV50, RV50, TF125
09167-17002	WASHER	A100, AX100, AX115, DS80, FR50, FR80, GP100, GP125, GT200, JR80, PV50, RB50, RG125, RG50, RG80, RH100
13382-42A00	RING	DF125, DF200, DR125, DR200, DR250, DR350, DR750, GSX1100
12140-14110-50	RING SET PISTON	RM125
62226-27C40	DUST SEAL	RM125, RM250, RMX250
09471-12071	BULB	EN125, GN125, GN250, GR650, GS1000, GS1100, GS125, GS400, GS500, GS550, GS650, GS850, GSX400, GSX500, GSX550
09381-10003	RING VALVE GUIDE	DR400, DR500, DR600, DR650, DR750, DR800, GR650, GS1000, GS400, GS425, GS450, GS500, GS550, GS650, GS850
64741-36A01	SPACER, RH	RG125, RG80
13551-46180	VALVE THROTTLE	PV50, TS50, ZR50
08314-41148	NUT	CL50, CS50, PE175, PE250, PE400, RM125, RM250, RM465, RM500
09283-25009	OIL SEAL	A100, TS185
13681-04010	CAP	AD50, AD60, AG50, AH75, AJ50, AP50, CL50, CP50, CP80, CS125, CS50, CS80, CS125, CS50, CS80, DRZ125, DR650, DR800, AD50, AD60, AG50, AH75, AJ50, AP50, CL50, CP50, CP80, CS125, CS50, CS80, DR2125, DR650, DR800, EN125

09180-10058	SPACER	PV50
		AE50, AX100, AY50, CL50, CP50, CP80, CS125, CS80, PV50, RG50, RG80, RM50, RM80, TS50, TV50, UF50
01421-06168	STUD BOLT	AE50, AX100, AY50, CL50, CP50, CP80, CS125, CS80, PV50, RG50, RG80, RM50, TS50, TV50, UF50
61273-46001	BUFFER, CHAIN TOUCH DEFE	PV50, ZR50
12911-49020	VALVE INTAKE	GS1000, GS1100
09140-22006	NUT	GR650, LS650, PE250, PE400, RM125, RM250, RM465, RM500
02112-06357	SCREW	A100, AG100, AX100, AX115, BX120, JS80, FB100, FB50, FB80, GP100, GS400, GSXR1100, GSXR400, GSXR750, JR50, K125
64651-01081	SHOCK ABSORBER	AX100, A100, AX115, FB100, FM50, PV50, RC50
14172-01821	GASKET EXHAUST PIPE	RM125
09283-30058	OIL SEAL RH	RM125, RM80
32341-22020	CONDENSER	PV50, RV50
61262-36E00	SEAL OUTER	DR400, DR2400, RM2250, RM125, RM250, RMX250, RMX450
13269-15011	SCREW AIR PILOT	DR400, FR50, FR80, GT250, RG125, SP370
11141-01832	GASKET CYLINDER HEAD	RM125
61341-01800	GUIDE CHAIN	RM125, RM250
11147-27C11	O-RING CYLINDER	RGV250, RM125
09285-16003	OIL SEAL	DF200, DR2125, DR125, DR300, EN125, GS125, GT250, RG250, RGV250, RM125
13881-48000	HOSE AIR INLET	TF125, TS100, TS125
11489-15501	GASKET	GR650
11483-01810	GASKET MAGNETO COVER	RM125
11241-00820	GASKET CYLINDER	RM250
11483-28C01	GASKET MAGNETO COVER	RM250, RMX250
09103-10120	REAR SHOCK ABSORBER	RG500
23111-28000	ROD PUSH	GP100, GP125, PE250, PE400
08316-26068	NUT	CL50, CS50, CS80, DR125, DR200, GR650, GS450, GS550, GS650, GSX1000, GSX250, GSX400, GSX750, RB50, RG125, RG80
35612-27A01	LENS	GSXR1100, RG80
64451-38210	LEVER BRAKE	RG125, RG80, TU250, VL125, VL250
09103-10120	BOLT	RG500
23111-28000	ROD BUSH	GP100, GP125, PE250, PE400
08316-26068	NUT	CL50, CS50, CS80, DR125, DR200, GR650, GS450, GS550, GS650, GSX1000, GSX250, GSX400, GSX750, RB50, RG125, RG80



35612-27A01	LENS	GSXR1100, RG80
64451-38210	LEVER BRAKE	RG125, RG80, T0250, VL125, VL250
56134-17200	STOPPER BRACKET	F250, PV50
01500-0625B	BOLT	DR.200, GD110, GSXR1000, GSXR1300,
		VL1500, VL250, VL800, VS1400, VZ800
09280-70001	O-RING	GS400, GS425, GS850, GSX400, GSX750
02120-17220	COIL LIGHTING	PV50
11381-00A00	COVER CONTACT BREAKER	GSX1100, GS1150
09180-06180	SPACER	GS500, VS1400
34125-04700	PANEL PILOT	RG125, RG50, RG80
K1106-10101	GASKET	RMZ250
57517-28400	BOLT	RMZ450
57153-28401	LEVER MASTER CYLINDER	RMZ250, RMZ450
44353-12C01	O-RING	AX100, AX115, BX120, GN125, GN250, GS125,
		FF125, TS125, TS185, TS50, VS1400,
		VB800, VZ800
02112-15128	SCREW	FA50, FB50, FM50, RGV250, RM125, RM250,
17431-02B10	GASKET WATER PUMP	BM80, RMX250, TS125
09116-05020	BOLT	ANG50, DF125, JF200, JR2125, DR125, DR200,
		DR350, DS80, EN125, GD110, GN125, GS125, GZ125,
		JR80, PV50, RG125
09283-25089	OIL SEAL	TS125, TS200
17510-36F00	SHAFT WATER PUMP	RM125
44346-28070	GASKET	A100, AX100, AX115, BX120, DR125, DR200, DR250,
02112-06457	SCREW	DR400, DR500, GN125, GN250, GT100, GT125,
		GS125, GT200, GT250
		A100, AD50, AD60, AE50, BX120, DS80, FA50,
		FB50, FB80, FH50, FZ50, GSXR400, GSX250,
		GV1400, K125, PE175
17414-14300	O-RING	RG125, RG250, RM125, RM250, RMX250,
		TS125, TS250
09440-19027	SPRING	GS1100, GSX400
13581-07910	SEAT SPRING	AD50, AD60, CL50, CP50, CP80, FN50, FZ50,
		PV50, TS50, ZR50,
01107-08355	BOLT	DR125, JR200, DR500, JR600, GSXR1100, GSXR400,
		GSXR750, PV50, RG250, RG80, RGV250, TS125,
		TS250, XN85
25352-11000	HOUSING STOPPER	GP100, GP125, GS400, GS425, GT200, PE175,
		PE250, PE400, RM100, RM125, RM250, RM465,
		SB200, TS100, TS125, TS185

24251-46001	GEAR 5TH DRIVEN	DS 80, JR 80
24351-46000	— " —	DS 80, JR 80, PV 50, RM 50, TS 50, ZR 50
09440-05007	GEAR SHIFTING	PE 175, PE 250, PE 400, RM 100, RM 125, TS 100, TS 125, TF 125
25351-11000	CHANGE CAM STOP	PE 175, PE 250, PE 400, RM 100, RM 125, RM 250,
09280-74002	O-RING	RM 465, TS 100, TS 125
		GS 1000, GS 450, GSx 1000, GSx 1100
09440-06023	SPRING	CL 50, CS 50
51153-28E30	OIL SEAL	RM 125, RM 250, RMx 250
11483-14100	GASKET	RM 125
09443-08001	SPRING	A 100, AX 100, AX 115, BX 120, DL 650, FM 50, GP 100, GP 125,
		GR 650, GS 250, GS 400, GS 425, GS 450, GS 500, GS 550, GSx 250
12140-20420	RING SET PISTON	RM 80
12140-25631	— " —	CP 80, CS 80, DS 80, FR 80, JR 80
26240-40201	GEAR KICK DRIVE	PE 175, RM 100
61342-27C00	PLATE GUIDE OUTER	RM 125, RM 250, RMx 250
11497-45000	GASKET	GS 1000, GS 1100, GS 850, GSx 1000, GSx 1100, GSx 750
32800-44120	RECTIFIER	GS 450
11483-43D00	GASKET MAGNETO COVER	RM 125
09263-22066	BEARING	RM 125, RM 250
62316-14100	SPACER LOWER	DR 125, DR 250, PE 175, RM 125, RM 250, RM 465, RM 80, TS 125
09101-08003	BOLT FRONT	DR 400, RM 100, RM 125, RM 250, RM 465, RM 500
09285-22003	OIL SEAL	RM 465
09200-08035	PIN	DR 125, DR 250, DR 400, DR 500, GSxR 400, GSxR 750,
		PE 175, PE 250, PE 400, RM 100, RM 125, RM 250, RM 465,
		RM 500, RM 80, TS 250
24751-32400	HOLDER OIL SEAL	DR 400, SP 370, SP 400
26449-33000	PLATE	DR 400, GS 1000, GS 1100, GS 250, GS 400, GS 425, GS 500,
		GS 550, GS 650, GS 850, GSx 1100, GSx 1000, GSx 1150,
		GSx 400, GSx 500, GSx 550
09263-22064	BEARING OUTER	DR 400, DRZ 450, RM 2250, RMZ 450, RM 125, RM 250,
08316-10087	NUT	RMx 250, RMx 450
		AG 100, DR 350, DR 650, DR 800, FB 100, GN 125, GSxR 750,
		GSx 1100/1150, GSx 400, GSx 600, GSx 750, LS 650, RG 50/125
23165-44B01	RACK	DR 650/350, RG 125, RM 80/85, TS 125
51571-03B20	SEAL JUST	RM 80
09283-20015	OIL SEAL, LH	GT 250
49700-38A01	FOOTREST ASSY, LH	VS 1400/600/750/800
31360-49240	THRUST SUPPORT	GR 650, GS 850/1100
51631-28000	NUT STEERING STEM	A 100, AH 100, AH 75, AN 125/150/250/400, AP 50, AX 100/11
		BX 120, CL 50, CP 50/80, CS 125/50
12110-03B00-050	PISTON	RM 80

33410-22220	COILASSY IGNITION	A100
17410-14300	WATER PUMP	RM250, T5250
09100-08287	BOLT	DL1000, DR2400, GSF1250, GSR600, GSXR1000/1100/1600/ GSXR750/1250F/1300R/1400/400, RGV250, RM2250
09160-10127	WASHER	AE50, AX115, BX120, GN125/250, GSXR1100, GZ125/250, PV50, TF125, TS185, TU125/250, UH125/200, UX125
61273-20901	BUFFER CHAIN DIFENCE	RM80
09263-18016	BEARING PISTON	RM250/465/500, RMX250, TS200
12141-28C10	RING PISTON	RM250
21481-29A01	SILENBLOC	CP50
11238-00B20	GASKET CYLINDER	RM250
44347-17270	CUP	PV50, RB50, RG50, TV50
12687-01B00	BUSH, NO2	RM125, RM250/80, RMX250
01500-08403	BOLT	GSXR750
02122-06167	SCREW	AD50/60, AE50, DR250/350/500/600/650, FB50, FB80, FZ50, GN250, GP100, GS1100, GS450, GSF400 GSXR1100, GSXR750, GSX600, GSX750, LS650
09106-10022	BOLT	DR2250/400, DR125/200/250/500/600/650, FB50, FB80, GSXR1100, GSXR750, GV1400, RB50, RC50, RG125
09169-06033	WASHER	GS450/500/550, GSX750, RG125, RM80
51152-45400	GUIDE BUSH	AE50, AG100, AN125/150/250/400/650, AX115, AZ50, DF125/200, DL1000, DL650, DR2250/400/125
09404-06432	CLAMP	AN250/400/650, DF200, DL650, DR400, DR2250/400, DR125/200/250/350/650/800/GD110, GS500
09180-06310	SPACER	RM80
12141-02B80-050	RING PISTON	DR500/600/650, GSXR750
35712-14A00	LENS	RM250, RMX250
14171-28C30	O-RING EXHAUST PIPE	GS1000
31440-36210	POINT ASSY CONTACT LH	A100, AD50/60, AE50, AG100, AG50, AH100, AH75, AJ50, AN125/150, AX100, AZ50, BX120, DR650, EN125
08319-21057	NUT	AD50/60, AE50, AN125/150, AX100/115, CP50/80, DR400, DRZ125/250/400/70, DR200/250
13601-04148	SCREW	GSX1100, GS1150
38860-49500	RELAY LAMP OUTAGE WARNING	RM250, RM80
61341-14201	GUIDE CHAIN OUTER	AN125/150, AP50, GR650, GS1100/450/500/550/650/ 850, GSF1200, GSF600, GSXR1100/750, GSX1100, GS1150
09250-06004	CAP	DS80, GP100, PE175, PV50, RB50, RG125/250, TS125/185, TS250
02112-06404	SCREW	GS500, GS650, GSX250/400/500/550
14771-47020	CONNECTOR MUFFLER	

61252-28000	SPACER, PIVOT INNER	RM125 / 250, RMX250
61262-15000	COVER	TS250
09160-22027	WASHER	RG250
51910-25311	LOCK ASSY STEERING	A100, AX100/115, BX120, DR125/250/500, FB100/50, FR80 FS50, GN125, GP125, GS125, RV50, TF125
59300-14810	PISTON SET, FRONT CALIPERS	DR500 / 600
11482-46010	CRANKCASE COVERS	DS80, JR80, PV50
94520-36A10	BRACE REAR LH.	RG125
32141-15320	COIL PRIMARY B	GT250
32142-15320	COIL PRIMARY A	GT250
11241-14231	GASKET CYLINDER	RM506
69108-32B00	SEAL WIPER	GS500, GS F400, GSXR1100, GSXR400, GSXR750, GSX1100, GSX600, GSX750, RF600, RF500, RGV250
09320-05006	CUSHION	DR500, FB100, G125/250, GP100, GP125, GS125/250/450/550 GSF600, GSX250, GSX400/500/550/750
01547-06307	BOLT	AN400, DR250/350/650/800, EN125, GS100, GS125, GS850, GSXR750, GSX1100, GS1150, GSX1200, GSXR1300, GSX1400, GSX250
09180-20039	SPACER	GP100, GP125, PE175, RH100, RM125, TF125, TS100, TS125, TS185
11241-14101	CYLINDER GASKET	RM125
14171-28C01	O-RING EXHAUST PIPE	RM250, RMX250
09180-15034	SPACER AXLE	GS250/400/425/450/500/650, GSX1100/1150 GSX250, GSX400
11115-37470	GUIDE VALVE EX	DR500/600/650, LS650
12686-01800	BUSH EXHAUST VALVE ROD	RM125 / 250 / 80 / 85, RMX250
34182-29330	CUSHION	DR400/500, PV50, TS100, TS250, TS50
61251-49000	SPACER	GS1000, GSXR1100, GSX1000/1100, GSX1100, GS1150 GSX750, XN85
57300-48500	LEVER ASSY BRAKE	TS100 / 125 / 185
09160-18002	THRUST WASHER	BX120, DR125, DR250, EN125, GP100/125, GS125, GS450 GS550/650, GSX400, PV50, RV50, TF125, TS100
09209-05011	CONTACT	A100, AX100/115, BX120, DF125/200, DL1000, DL650 DR400, DR2250/400, DR270, DR125/200/250/350 GN250, GS1000/1100, GS250/450/850, GSX250/400/750 " "
59305-45200	AXLE NO1	
59306-45200	AXLE NO2	
13156-01C10	GASKET REED VALVE	RM250, RMX250
11115-45740	GUIDE INTAKE VALVE	DR400, GR650, GS1000/1100, GS450/500/850, SP400, VL1500, VS1400
61342-14201	PLATE CHAIN GUIDE IN	RM250, RM80
13581-09210	PLATE THROTTLE VALVE	A100, AX100, AX115, BX120, DS80, GS125, JR80, X17 RG80, RM50



03211-04208	SCREW	AX100, CS125, CS50/80, DR250/500, FA50, FB100, FZ50, GN125/250, GP125, GR650, GS1000/1100, GS125
09385-06012	CLIP	DR250/350, GZ125, RMX250, RV125, TS200, TU250, UZ50
61345-14100	DEFENSE UPPER	RM125/250/465/500/80
12211-46101	PIN CRANK	RM50
23160-06B02	CYLINDER CLUTCH RELEASE	GSF1200, GSXR1100, GSX1200, GSXR1300, GSX1400, RF900
54711-04410	AXLE FRONT	JR50
64430-14600	SPRING	RM250/500
32101-20921	MAGNETO	RM80
09180-08077	MUFF FR SPACER	GV1400, PV50, SP370, SP400
1174-49210	CAP CYLINDER HEAD COVER	GS250, GSX1000, GSX400, GSX750
14470-01A01	BRACKET 2ND MUFFLER	TS125
09160-08004	WASHER	DR250/350, DS80, FB100, FB50, FB80, LS650, PV50, RGV250, TF125, TS100, TS125, TS185/250/50, VS1400
62657-34A01	RING STOPPER	DR250/350/650/800, GSXR1100, RM250/80/85, TS125
11241-01B00	GASKET CYLINDER	RM125
43561-40401	FOOTREST FRONT LH	DR125/250/500, PE175, RM125/250/465/500/80, TS250
64352-40401	BEARING	DR500/600, RM125/250/465/500, TS125/250
02162-06203	BOLT	AN250/400, DL1000/650, DRZ250/400, DR650, GN125/250
09262-30102	BEARING	GS500, GSF1200, GSF600, GSX1400, GZ125/250, LS650
09167-20012	WASHER	TR50, UG110
13581-29500	PLATE SPRING	DR125, EN125, GN125, GS125, PE175, RM100/125
08322-11107	WASHER	GT250, RG125, RM80
09262-25049	BEARING	DR125/200/250/350, FA50, FH50, FZ50, GP100, GSF400, GSXR1100, GSXR400, GSX750, GSX1100, GSX1100/1150, LS650, PV50
09241-22002	PLUG	RG125, TF125, TS100, TS125
51153-40300	OIL SEAL OUTER TUBE	CS125, DF125, DF200, DRZ125, DR125, DR200, EN125, GN125, GS125, GZ125, RV125, TV125, VL125, VL250
51173-28000	SEAL DUST	PE175, RM125, RM250
14771-12B00	CONNECTOR	RB50
09111-08048	BOLT REAR	RG125
13154-19011	SCREW	RM80
09111-08012	BOLT FRONT	RG50, RG80, RM50/80, TS100, TS125, TS185, TS250, TS50, TV50, ZR50
35627-43010	GASKET	A100, AX100, AX145, DR250, EN125, GD110, GN125, GN250, GP100, GP125, GS125, GT200, GT250, GZ125, GZ250, RG125
		AE50, AX100, CL50, CS125, CS80, DF125, DF200, DRZ400, DR125/200/250/400/500/600/650/750



64430-40300	SPRING	CS125, TS125
08319-31067	NUT	AH100, AH75, AX100, AX115, DF125, DF200, DRZ125, DRZ250, DR125/200/250/350/750/800, DS80, GS125
25600-48700	LEVER ASSY GEAR SHIFTING	TS125
26211-14A02	SHAFT KICK STARTER	DR650
26260-46001	GEAR KICK STARTER IDLE	DS80, JR80, PV50
11241-14600	GASKET	RM250
08310-12088	NUT	A100, CL50, CS125, DR125/200/250/400/500, DS80, FB50, FB80, FM50, FR50, FR80, FZ50, GN125, GS500, GSx500, GSx550
21441-45001	PLATE DRIVE	RG125, RG80
43110-36A01	PEDAL BRAKE	GP100, GP125, TS100, TS125
21441-36200	PLATE DRIVE	GS125, CS50, CS80, DR125, DS80, GN125, GP100, GP125, GS250, GSXR400, GSx250, GT200, PV50, RG125, RG50, RM125
21451-28000	PLATE DRIVEN	RM250, TS250
09180-22026	SPACER ENG SPROCKET	AN125, /150/250/400/650, DF125/200, DL650, DR400, DRZ400, DR125, DR200/250/350, EN125
09280-24003	O-RING	A100, BX120, DR125, DR250, FM50, FR50, FR80, FZ50, GD110, GP100, GS125, PV50, RV50, TH25, TS100
09134-03101	SCREW	DF200, DR2250, DRZ400, DR250/350/400/500/600/650, GN250, GSF400, GSXR400, GT200, GZ250, PE175
09380-22006	4TH DRIVE GR CIRLIP	RM250, RMX250
11241-28C11	GASKET CYLINDER	CP50
54611-03A10	GEAR SPEEDOMETER	DL650, GSFI200, GSFI250, GSXR1100/1150, GSX1200, GSX1250F, GSX1300BK/GSX1300R, GSX1400, SFV650, SV650
12164-46E01-000	BEARING CRANK PIN	AG100/50, AJ50, AN125, AN150, DL100Q, DL650, DR650/800, EN125, GN125/250, GS125/500, GSFI200, GSFI250
55156-66310	CAP	DR200, PE175, PV50, RG125, RM125/250, RM80
02112-06555	SCREW HOLDER UPPER	A100, DR250/350/400/500, FB100, FB50, FB80, FR50/80, GR650, GS1000, GS1100, GS250/450/500
09160-06004	WASHER	DR200/250/350/650, DS80, GSF400, GSXR1100, GSXR750, GSX1100, GZ125, JR50, PV50, RM80, RMX250, TS50
08310-11057	NUT	GSX250, PV50
09118-06045	BOLT	GS400/425/650/850, GSX400/500/550/750, GZ250, PE250, RGV250, RM250, SF370, TS250, XN85
21451-31000	PLATE DRIVEN NO1	

54661-29300	DRIVER	DR125/250, TF125, TS100/125/185
44300-38B13	FUEL COCK	V51400, V2800
12100-46410-050	PISTON SET	DS80, JR80
24741-28001	HOLDER BEARING	TS185
01517-08405	BOLT LOWER	DR250/350/500/650/750/800, GSXR1100/400/750, GX1100, RF600, RG125/250/500, TS125
09448-18029	STRING, LH	DR400, DRZ450, RM125/250, RMZ250
27511-14300	ETURATAS (14)	DR250/350, RM250
09200-06065	PN	DR250/350, RMX250, TS200

16731-03101	GASKET	A100, AX100/115, BX115, DS80, FM50, FR50/80, FZ50, GP100, GT200/250, JR80, K125, PV50, RM125
12110-14513-050	PISTON	RM250/465/500
64711-14201	AXLE REAR	GN125, GS500, GS650, GSX250/400/500/550, GZ125
09168-08013	GASKET	GS650, GSX1000/1100/1150, GSX750
11491-49200	GASKET	AY50, FM50, PV50, RG50, RMX50, SHX50, TS50, TV50
12161-04710	ROD CONNECTING	A100, AN125/250/650, AX100/115, BX125, CL50, GS125/50/80, DR400, DR2250/400
09168-10002	GASKET	AD50/60, DR125/500/600, FA50, FB50/80, GN125, GP100, GS125, GSXR1100/400/750, GSX1100/1150
08321-21846	LOCK WASHER	DR400, FB50/80, FA50/80, FZ50, GN125, GP100/125, GT200, JR50, K125, PE250M/400, PV50, RG125, RG500
09100-06091	BOLT	DR650/800, GSF400/600, RM125/250, RM2250, Vx800, JR50
11241-20A03	GASKET CYLINDER	CL50, CP50, CS50, FA50, FM50, FR50, FS50, FZ50, JR50, PV50, RM50, RV50, TS50, ZR50
51167-28C00	METAL SLIDE	RM125
09283-22001	OIL SEAL	GSXR1100
12140-46110-100	RING PISTON	RG500
12140-14110-025	RING SET	DF125/200, DR125/200/250/350/650, RM125/250, RM80, RMX250, TS125
09180-25081	SPACER	RM80
11242-20A00	GASKET CYLINDER	RM80
09444-11005	SPRING	K125
12140-02B10	RING SET PISTON	RM125
12141-02B60	RING SET PISTON	RM80
12141-20300	RING SET PISTON	RM80
09263-20022	BEARING	K125
12161-27C10	ROD CONNECTING	RM125
09440-15013	SPRING	GS250, GSF250/400, GSX250, RM125/80
09440-16016	SPRING	RM80
11233-00B20	GASKET CYLINDER	RM250
14771-14600	GASKET	DR125, RM250
09448-41003	KICK STARTER	AX100/115, DR500/600/650, TG125
09262-08005	BEARING	RM125/250/80/85, RMX250
09285-14001	OIL SEAL	CL50, CS50/80, DR270, DS80, FA50, FB100/50/80, FS50, FZ50

08331-31258	CIRCLIP	GS1100/650/850, GSXR1100/750, GSX1100/1150
08211-22341	PLATE	GSX750, RM250, XN85
		DR500/600/750/800, GSF1200/600, GSXR1100/750, GSX1100/1100, GS1000/1100/1150,
		GSX600/750, RF600/900
12141-41620	RING PISTON	RM250/RMX250
59107-39108	SEAL	DR800, GN125, GP125, GS125/450/500,
09280-19005	O-RING	GSF400, GSX1100/1000, GS1150, GSX250/400,
		RG125/50/80, RGV250, TV50
		AE50, A250, DR125, GN125, GS125, GSF400,
		GSXR400, GZ125, TR50, TU125, VL125
12110-14513-025	PISTON	RM125
61372-38A00	BOOT PROPELLER SHAFT	V5600/750/800, VX800
61348-14510	DEFENSE	RM125
17491-20900	IMPELLER	RM80
27516-19000	HOLDER DAMPER	GSX600
09283-33002	OIL SEAL	GSX500/550/750
01500-12163	BOLT	GN250/GZ250, RM125/250, TU250
44200-27860	CAP SET FUEL	RM125/250/80
09360-10018	BOLT	GS1100/850, GSF1200/400/600, GSXR400,
		GSXR750, GSX1100, GS1150, GSX400/500/550
		GSX600/750, GV1400, RF600
35712-11521	LENS	GS450, GSX250/400
56111-09310	HANDLEBAR, RH	XN85
12151-36A00	PIN PISTON	RG125
11177-31300	GASKET	GSX1100/GS1150, GSX750
09280-21068	O-RING	DF125, DF200, DR400, DR2125/400, DR125/200/400, FB100, FL125, GD110, GN250, GSF1200/600/650
09168-05010	GASKET	GR650, GSX500/1100, GS250/400/425/450/550/850/GSX1000/GSX1100/1150, GSX250/400/750
		GV1400, RMX250
09282-08004	OIL SEAL	RG125, RGV250, TS125
35611-49230	RIM	AX100, GR650, GS1000/1100, GS125/450/500/550
		650/850, GSX1000/1100/1150, GSX250/400
		GSX750, GT250
12140-20900	RING SET PISTON	RM80
X1106-10027	GASKET	RM2250
01517-08508	BOLT	DR250/400/500/600/750/GN250, GS1000,
		GS125/250/450/500/550/650, GSX1000,
		GSX1100/GS1150, GSX250



59151-16701	COVER	GS500,GSF1200/250/400/600,GSXR1100/400/600/750, GSX1100/1150,GSX1200/1300R,GSX250/400/550
09285-10004	OIL SEAL	DL650,DR250,DR125/250/350/650/750/800,DS80 GD110,GSR600,GSXR1000/600/750,PV50
32800-01A01	RECTIFIER REGULATOR	RG125,TS125
88341-31069	KEY	TL1000,TS250
09284-10002	OIL SEAL	FR50,PE175,RM100/125
87431-17C00	BOLT KNOCKER	ANG50,DL650,GN250,GS500,GSF1200/250/400/600/650 GSXR1000/1100,GSXR400/600/750/1100/651000/1150
17461-28C10	OIL SEAL	RM125/250/80,RMX250
61262-28C10	COVER	DR250,DR250/350,RM125/250,RMX250,XF650
12837-27A10	GASKET ADJUSTER	GSF1200/600/650,GSXR1100/750,GSX1100/1150/1200/ 600/750,RF600,RF300
09169-08012	WASHER	BX120,EN125,GN125,G*125,GS125,GT200,RF900,RG125 RG80,SB200,TU125
09119-08052	BOLT	RG125/80
09140-10041	NUT	A100
09200-06030	PIN	PV50
35652-44182	LENS	GR650,GS1100/450/500/550/650/850,GSX1000/1100/115. GSX250/400/750,XN85
K9205-50010	RING O-WATER	RMZ250
17431-28C00	GASKET WATER PUMP	RM250,RMX250
11482-28C01	GASKET CLUTCH	RM250,RMX250
09283-25086	OIL SEAL	RGV250
12151-35400	PION	AH75,CB80,C580,VR80,RG80
12140-2D440	RING SET PISTON	RM80
57110-49501	GRIP THROTTLE	GS1100,GSXR1100,GSX1100/600/750,VX800
09448-14018	SPRING	DR250,PE175,RM125/250,RMX250
11241-14110	GASKET	RM125
69107-45000	SEAL PISTON	GS1000/550/850,GSX1000/450,GSX750,XN85
12140-20440-050	RING SET PISTON	RM80
09280-00015	O-RING	GS650,VL800,V5600/750/800,VX800,VZ800
12161-28C00	ROD CONNECTING	RM250
68111-48E20	EMBLEM FUEL TANK	VZ800
12140-19A10-100	RING SET PISTON	TS250
12141-02B70-100	RING PISTON	RM80
14181-03D01	GASKET EXT. PAYS	TS125
44300-01D21	COCKASSY FUEL	GS500
14182-27A00	CLAMP EXT. PIPE	GSXR1100/750/750
13295-03D00	O-RING	TS125/200
13152-14500	STOPPER	RG125,RM125,TS125

09280-17002 O-RING SEAL NUT	GSF1200/600/650, GSXR1100/750, GSX1000/1100, GS1150, GSX1200/500/550/600/750, RM250
11177-45400 GASKET	GSX400/750
44261-36000 GROMMET INLET	AH100/75, AN125/150, AP50, UF50
44200-21400 CAP ASSY FUEL TANK	AY50, UC125/150, UE125/150, UG110, UH125/150 AY50,
14181-48E00 GASKET MUFFLER	UC125/150, VZ800
09159-10058 NUT	AE50, AG100, AJ50, AN125, AZ50, DL1000/650, DR2125/ 400/250, DR200/250/350/650/800
61342-02D40 PLATE GUIDE OUTER	DRZ125, RM80/85
11241-28001 GASKET CYLINDER	RM250, RMX250
17431-02B41 GASKET WATER PUMP	RM80/85
09740-22D01 BRACKET UNDER COW.	RGV250
09180-17051 SPACERS	PV50, TS50, ZR50
09168-08021 GASKET	AN125/250, DF125/200, DRZ125, DR200, FB100, FL125, GN125, GS125, GSF1200/600/650, GSXR1100/400
12141-41600-025 RING PISTON	RM250
57211-34310 GRIP LH	GS125, GSF400, GSXR400, RG125/250/500/80
17858-36A00 HOSE WP OUTLET	RG125
08211-20321 THRUST WASHER	DR750/800, FH50, GSF400, GSXR400, GSX250/400, RG500, RM125/80, VS1400, XN85
11233-02B41 GASKET CYLINDER	RM80/85
09169-06034 WASHER	AD50/60, AE50, AG100, AH100/75, AP50, AY50, CP50, DR125, DR650/750/800, GR650, GSX1100
01547-06167 BOLT	AN400, DR650/800, GSXR750, LS650, RG125, RGV250, RM125/ 250/80, RMX250, VL800, VS1400/600/750/800
61341-01B02 GUIDE CHAIN	RM125/250
64611-01001 DRUM SPROCKET MOUNT.	A100, FB100/50/80, FH50, FR50/80, PV50, AB50, RC50, RV50, ZR50
09159-08067 NUT	DR200, RMZ250/450, RM125/250/80/85, RMX250
K1106-10030 GASKET CLUTCH COVER	RMZ250
K3402-81533 STEP LH	RMZ250
09139-06050 SCREW	DRZ250, DR250/800, GSXR1100/400/750, RG125, RGV250
09381-21002 CIRLIP	DR500
59312-36500 BOOT	AG100/50, AH100/75, AJ50, AN125, DRZ125, DR600/650/800 GN125, GS125/450, GSX400
07130-06355 BOLT	GSXR1100/400, GSX1100/650/1150, GSX750, GV1400, RF600, RG125, RGV250, TS50, TV50
09106-06024 BOLT	CS50, DR125/200/250/500, FB100, GN125, GS1000/125/250/ 480/425/450/550/850, GSX1100/650/1150

07130-06355	BOLT	GSXR1100/400, GSX1100, GS1150, GSXR750, GV1400, RF600, RG125, RGV250, TS50, TV50
61211-14102	SHAFT RR SWING PIVOT	FE175, RM125/250/465/500
62226-28C00	DUST SEAL REAR	RM125/250/80/85, RMx250
62624-44B10	DUST SEAL SWINGING ARM	DR750, RG125/80, TS125/50
09284-10006	OIL SEAL	GS1100/450/500/650/850, GSX1100, GS1150, GSX250/400/500/550/750, XM85
61222-14500	BF CAP SWINGING ARM PIVOT	RM125/250, TS125
11233-28C21	GASKET CYLINDER	RM250, RMx250
12110-01B41-025	PISTON	RM125
17431-28C10	GASKET WATER PUMP	RM250, RMx250
57437-32C00	BOLT	GS500, GSF400, GSXR1100, GSX1100, GS1150, GSX250, GSX600/750, RG125, RGV250, VX800
11483-00B20	GASKET	RM250
14181-23E00	GASKET	GSF250/400, GSX250/400, RGV250
01547-06258	BOLT	DR400, GS1000/450/500/550/650/850, GSX1000/GSX1100, GS1150, GSX250/400/750
62226-43D00	DUST SEAL REAR	RM125/250, RMx250
12140-02B40	RING SET PISTON	RM80
12911-44B00	VALVE INTAKE	DR750/800
26234-37400	SPRING	DR500
09284-15006	DUST SEAL	DR400, DR2250/400, DR250/350, RM2250/450, RM125/250/85, RMx250/450
13881-45050	HOSE RH	GS1000
08143-63007	BEARING	A100, AX100/115, DR2125, DS80, FB100, FM50, FR50/80,
57421-14502	LEVER BRAKE	GP100, JR80, PV50, RC50, RM50, TS50, RM80/125/250
21441-31D00	PLATE DRIVE	DR650/800, XF650
09280-32006	O-RING	AN125/150, CS125, DL650, DR125, EN125, GN125, GS1000, GS125, GSXR400, GSX400, GV1400, GZ125, RV125, TO125, UC125
09134-06013	SCREW	RG125, RGV250, RM125/250/80/85, RMx250, TS125
12141-02B70-050	RING PISTON	RM80
09263-14024	BEARING PISTON PIN	RM125
11483-00B20	GASKET MAGNETO COVER	RM250
09166-12007	WASHER	RM125
11241-02100	GASKET	CL50, CS50
13249-02500	GASKET	CL50, CP50, CP80, CS50/80
54611-17201	GEAR	PV50
03541-05163	SCREW	AE50, AG100, AG50, AH100, AJ50, AN125/150/250/400, AP50, AZ50, DL1000/650, DR2125, GS500, GSF1200



69602-00021	YOKE	DR250/350/800, RM125/250/80/85, RMx250
09160-19006	WASHER	A100, AX100, DR125/200/250/350/400/500/ 650/750/800, FB100/50/80/FM50/FR80
00285-33009	OIL SEAL	RGV250
12151-01841	PIN PISTON	RGV250, RM125
09263-15040	BEARING PISTON PIN	RM125
12141-27000	RING PISTON	RM125
01421-08358	STUD BOLT	RG125, RGV250, RM125/80/85, TF125, TS100, TS125
15741-09300	SEAL RING	XN85
02112-06128	SCREW	A100, CL50, CP50, CS125, CS50, CS80, DR125/200/250/ 350/400/500/750/800, DS80, FA50
13739-48610	TUBE JOINT	VLR1800, V2R1800
59107-34020	SEAL PISTON	GS1000/500/850/650, GSx1000/1100/651150, GSx750, GT200/250, XN85
09289-05011	OIL SEAL	AN125/150/250/400, DRZ400, DR125/250/350 EN125, GSF1200/600/650, GSXR1100/750, GSx1100
13821-00011	SLIDER	CL50, CS125/50/80, FA50, FM50, GS450/650, GSx400, PV50, RC50, TS50, ZR50
51125-45420	SPRING	GSx1000/1100, GS1150, GSx500/750, RG250
11285-03000	SPRING EXHAUST	RG125, TS125, TS200
09169-06010	WASHER	AN250/400, DF125/200, DR125/200/400/500/600/650 EN125, FM50, GS1000/125/500, GSXR1100
01547-06958	BOLT	DR400, GSx1000/1100, GS1150, GSx750, RM250, RMx250
13268-35010	SPRING	AD50/60, AE50, AG100/50, AH100/75, AJ50, AP50, DRZ70/125, FA50, FB100/50/80, FR50
12110-02832-050	PISTON	RM80
K1100-46003	GASKET HEAD	RMZ250
61262-41500	COVER	CS80, DR500/600, GR650, GSx1100, GS1150, GSx500/550/ 750, RM100/80, TS125, XN85
12931-49200	SEAT	CS125, DR125/200, GN125, GS125/250, GSx1000, GSx1100, GS1150, GSx400, GSx750
09285-35001	OIL SEAL	GS500, GSF1200, GSF250/400/650, GSXR1100/400/ 750, GSx1100/1200/250/400/600, GSx650 F, GSx750
09168-10031	GASKET	DRZ250, DR250/750/800, GS500, GSF1200/1250, GSF600, GSF650, GSXR1000/1100, GSXR600/750, GSx1100, GSXR600/750, GSx1100, GSx1100/GS1150, GSx1200
61421-38200	PLATE	DRZ125, DR125/250, GZ125, RV125, TS125, VLR25/250
09280-44005	O-RING	GSF250/400, GSXR1100/400/750, GSx250/400, RF600, RF900, RG500, RGV250
51353-11050	NUT	DRZ125, GSF250, GSx750, RM85



12151-10300	PIN PISTON	GSF400
57442-11010	NUT LOCK	AX115, DF200, DL650, DRZ400, DR125/200/250/400/500/650, GN125/250, GP100/125, GA1000/1100
65320-00300	SPOKE ASSY REAR	RM250
K1201-11053	COLLET	DRZ110, RMZ250
09200-06004	PIN	DF125/200, DRZ125, DR125/200/250/500/600/650, DS80, EN125, GN125/250, GS125, GV1400, GZ125
11234-37E30	GASKET CYLINDER	RM250
12211-48001	PIN CRANK	RM125, TF125, TS100/125
09285-43001	OIL SEAL	A100, AX100/115, DR125/250, FM50, FR50/80, GP100, PV50, RG50, RV50, TF125, TS100/125/185
64451-14100	LEVER RR BRAKE	RM125/250/465/500
25310-37400	CAM GEAR SHIFTING	DR500/600/650, XF650
11481-36F00	GASKET	RM125
15710-09300	O-RING	GSXR750, TL1000, XN85
11241-27C01	GASKET CYLINDER	RM125
09206-10005	PIN	LS650
08316-16064	NUT	DR125/200/250/350/500/600/650/750/800, GN125, GS450/500/ 850, GSF400
61251-14600	SPACER	RM250
32140-46120	COIL PRIMARY	PV50
12140-20910-050	RING SET PISTON	RM80
09319-08035	BUSH	RGV250
K9203-31270	RING SNAP	RMZ250
24741-21A00	RETAINER SHIFT	DL1000/650, DR400, DRZ400, DR250/350/800, LS650, RG500 RMZ250/450, RM125/250/80/85
64751-40600	SPACER LH	GSXR1100/750
09128-06041	BOLT	GSXR400, LS650, RM250, TS125
09125-06045	SCREW	RM125/250/80, TS125/250
09262-25108	BEARING R.H.	RG125, RM250, RMX250
09106-06057	BOLT	AN250/400, GSXR750, RG125/80
61273-01500	BUFFER CHAIN DEFENSE	RM125/250
43110-27C00	PEDAL BRAKE	RM125/250, RMX250
55320-02B00	SPOKE SET FRONT	RM80/85
02112-06608	CROSS SCREW	A100, CG125, DR400, FM50, FR80, GS1000/250/400/425, K125, PE175/400, PV50, RM125/250, RV50
09135-06009	BOLT	PE175, RG125/500, RGV250, RM100/125, TF125, TS125/185/ 200/250
09448-14014	SPRING	PE175, PE250/400, RM100/125/250, RMX250
09105-08001	BOLT	A100, AX100/115, BX120, FB50, FH50, FR50/80, GP100, GS250, GT250, PV50, RB50, RV50

02112-06308	SCREW	AD50/60, CL50, CP50, CS125/50/80, DR500/600/750/800, FA50, FB50/80, FM50, FR50
08332-11078	E-RING	DS80, GS250/450, GSX250/400, RM50/80, TS50, ZR50
11141-21A02	GASKET CYLINDER	RG500
62646-02B02	SPACER ROD	RM80/85
25211-36E10	FORK NO 1	RM125
24331-35G00	GEAR 3RD DRIVEN	RMZ450
57211-40201	GRIP LH	DR500/600, PE175, RM125/250/465/500/80, TS250
09259-04001	CAP LEAD WIRE	PV50, RM50
08322-21108	WASHER	A100, CS50, DR125/250/350/400, DS80, FA50, FB50/80, FM50, FR50/80, FS50, FZ50
09180-06239	SPACER	RG125
09250-06008	CAP	GR650, GS500, GSF1200/1250/400/650, GSXR1100/400/750, GSX1100, GS1150, GSX1200, GSX1250F, GSX250/400/500
09262-17049	BEARING CNTR SHAFT	RM125
37510-10E00	SWITCH ASSY	AP50, AV50, UF50, UX50
08321-21107	LOCK WASHER	DR125/200/250, DS80, FA50, FB50/80, FM50, FZ50, GN125/250, GP100, GS1100/450, GSXR1100/750
11277-22D01	CABLE EX VALVE REAR RH,	RGV250
03211-04258	SCREW	CL50, CS125, DR125/250/400/600/650, FR50, GP100/125, GSXR750, RM50, TS100/125
08310-22108	ECROU	A100, CL50, CP50, CS125/50, DR125/250/400/500, FR50/80, GP100/125, GR650, GS1000
07110-10258	BOLT	GS1100, GSXR1100/450, GSX1100, GS1150, VS750
11279-22D01	CABLE EX VALVE REAR,	RGV250
34910-01A11	CABLE SPEEDOMETER	TS125
11141-28C10	GASKET CYLINDER HEAD	RM250, RMX250
11483-37E00	GASKET MAGNETO COVER	RM250
11481-37E30	GASKET CRANKCASE	RM250
11241-01B20	GASKET CYLINDER	RM125
11148-27C11	O-RING CYLINDER	RGV250, RM125
09280-99003	O-RING	GS1000/400/425/550/850
61410-31001	ADJUSTED CHAIN	GS1000, GSX1000/1100, GS1150, GSX750
51173-43D00	SEAL DUST	RM125/250, RMX250
11482-00B20	GASKET CLUTCH COVER	RM250
68131-45130	EMBLEM	GS1000
11483-05210	GASKET MAGNETO COVER	DRZ125, DR125, GS125
13246-43010	D-RING	DR400, DRZ125/250/400, DR125/400, EN125, GS1000/125/500, GSF1200, GSX1000/600/750, GZ125/250
08314-40187	NUT	AN650, DL650, RF600, SV650
57110-40810	GRIP SET THROTTLE	PE175/250/400, RM100

09263-20040 BEARING RH	GR650, G5F1200/250/400/600/650, G5XR1100/400/650/750, G5X1100, G51150, G5X1200/1300BK/1300R, G5X1400
08321-21088 LOCK WASHER	A100, CL50, CS125, CS50/80, DR125/200/250/350/400/500/600/650/750/800, DS80
09181-22130 WASHER 3RD DRIVEN	RMZ450
12912-49020 VALVE EXHAUST	G51000/1100
62623-15500 SPACER	GR650, G5X750
09168-16002 GASKET	AN250/400/650, DL1000/650, DR350, G5650, G5F1200/250/400/600/650, G5R600/750, G5XR1000
34184-12000 SCREW	DF125/200, DR200/250/350/650, G5X600, RMX250
12211-02B42 PIN CRANK	RM80
09167-22005 LOCK WASHER	DR500/600/650, GR650, G5X400, LS650, PE250/400, RG500, RM250/465/500
57122-14301 GUIDE PIECE	PE175, RM125/250/500, RMX250
43610-03001 BAR PILLION FOOTREST	A100, AX100/115, BX120, DF125/200, DR200/250/350/400/650/750/800, EN125, FB100
59669-07000 CAP	DR800, G5XR1000/400/600/750, G5X600/750, RG125, RGV250, SY1000/650, TL1000
02112-06407 SCREW	A100, AD50/60, AE50, FA50, FB100/80, FM50, F250, JR50, K125, PV50, RB50, RC50, RG80
13156-46001 GASKET REED VALVE	DS80, JR80, RM50/80, ZR50
09285-25001 NO DESCRIPTION	A100, FM50, FR50/80, GP100, K125, PV50, RB50, RC50, RG50, RV50, TS50, TV50, ZR50
57114-14301 ROTOR THROTTLE	PE175, RM125/250/500, RMX250
09448-31018 SPRING RR. LEVER	PE175
27511-14210 SPROCKET ENGINE 14	RM250/465
02112-05256 SCREW	DR750/800
02112-06409 SCREW	AE50, AN125, DS80, JR50/80, PV50, TS125/185, VE125/250
68131-49540-73H EMBLEM LH, RH	G5X1100, G51150
02112-05205 SCREW	AH75, DR125/250/350/650/800, FR80, GN125, GP100, G5XR1100/750, G5X1100, G51150, G5X500/550/750, GV1400
51189-08300 CAP	DR350, RM125/250, RMX250, TS200
11483-32E00 GASKET MAGNETO	DR650, XF650
35710-14J20 LAMP ASSY TAIL	DR250/350/650
51121-31300 PISTON	G5X750
66152-98300 FILTER	PV50, RB50, RG50, TV50
35652-39280 LENS	GN125/250, GP100/125, GS125/250/400/425/450/550, G5X400, GT200, RV50, SP370/400, ZR50
11241-19A00-H17 GASKET CYLINDER	TS250
12912-31300 VALVE EXHAUST	G5X750
61431-04702 PLATE CHAIN ADJUSTER	DS80, JR80, RG50, TS50, TV50



08322-11128 RONDELLE	CP50/80, C580, DR125/200/250/400/500/600, DS80, FA50, FM50, FR80, FS50, FZ50, GN125, RM250/465
61410-14220 ADJUSTER CHAIN	DR500/600/650/750/800, RG125, TS125, TS200, XFG50
09111-06039 BOLT	GT200, RG125, SB200, TS125/200
27512-36200 PLATE ENGINE SPROCKET	AM250/400, GSX250/600/750, VH125/150
54637-19C00 CAP	RM125/250
57110-28E00 GRIP THROTTLE	DR400/500, GS1000/1100/400/425/500/550
09280-32005 O-RING	GSX1000, GS1100/1150, GSX750, SP370/400
59303-13A00 BOOT	DF125/200, DR125/200/250, RM125/250, TS125/250
51153-14140 OIL SEAL	RM125, TS250
09280-15006 O-RING	GR650, GS500, GSX1100, GS1150, GSX500, RM250/80/85
11147-03B00 O-RING CYLIND. 1	RM80/85
11148-03B00 O-RING -11- 2	RM80/85
11612-36A00 SPACER	GSXR1100, RG125
12140-21A31-100 RING SET PISTON	RG500
57211-49510 GRIP LH	GS450/850, GSXR1100/750, GSX1100, GS1150, GSX250/400
59308-36500 BOOT PISTON	GN125, GS125/450, GSX400, RG50, TV50, ZR50
51169-47400 RING STOPPER	DF125/200, DR125/200, GR650, GS450/500/550, TS125
11241-36A00 GASKET CYLINDER	RG125
09140-20001 NUT	A100, BX120, DL650, DR400, DRZ400, DR350/650/800, GP100, GP125, GS500, GT200, K125, RG125, RGV250, RM125
51196-24A00 RING PISTON	DR650, GSXR1100/750
51153-03400 OIL SEAL	DS80, JR80, PV50
57431-13D10 BOLT	DR125/200/250, GN125, GS125, RB60, RG125, RG50/80
59107-18410 SEAL PISTON	TS125/250, TV50, ZR50
56242-28C60 DAMPER LOWER	GN250, GS1000/1100, GS500/550/650/850, GSX400, GSXR1100/400/750, GSX1000/1100, GS1150, GSX250/400
56243-42A00 SPACER	DRZ400, DR125/200, GSX1200, RM2250/450, RM125/250, RMZ250
33172-36210 POINT ASSY CONTACT, RH	DF125/200, DL1000, DRZ400, DR125/200, GSX1200, RM250, RMX250
09148-05023 NUT	GS1000
12140-40A10-050 RING SET PISTON	DR350/650, GSXR1100/400/750, GSX1100, GS1150, RG125/80
68121-48G00 EMBLEM LH	RGV250, TS125
K1106-10025 GASKET CYLINDER	RG125/250
55700-27820 LOCK ASSY SEAT	VZR1800
31132-27A01 HOLDER BRUSH	RMZ250
	RG80
	AN650, GN250, GS500, GSXR750, GSX1300BK, GSX1300R, GSX750, GZ250, TU250



59600-03810 PISTON CUP SET	AG100/50, AH100/75, AJ50, AN125/150/250/400, AP50, DR500/600, RB50, RM125/250/80
11238-27C30 GASKET CYLINDER	RM125
12151-08001 PIN PISTON	GS500/550, K125, UC125, UH125
12110-02B43-050 PISTON	RM80
12110-18401 MÄNTÄ GT250	GT250
13247-45010 SCREW	DR400, GS1000, GSX1000, SP370
11484-28C10 O-RING CLUTCH COVER	RM250, RMX250
12141-02B50-050 RING PISTON	RM80
12110-02B52-050 PISTON	RM80
57460-10400 STOP SWITCH	AX115, DR125, GS125, TS50
13383-28C20 NEEDLE JET	RM250
12141-02B60-050 RING PISTON	RM80
11233-27C10 GASKET CYLINDER	RM125
09381-15001 CIRCLIP	AN150, GSXR1000/400/600/750, GW250, RGV250, RM125, UE150 UX125/150, VL250
68691-08F40 EMBLEM LH	GSX600/750
11371-36E10 COVER CLUTCH OUTER	RM125
09159-14008 NUT	GN125/250, GS125, RG125/80, SP370, TS125, TU125
57442-14200 NUT	DR2125, RM125/250/465/500/80/85
08319-31087 NUT	A100, AD50/60, AE50, AG100/50, AH100, AJ50, AN125, AN150, AX100/115, DF125/200, DR2125/250
11141-02B60 GASKET CYLINDER HEAD	RM80
43534-36A00 COVER FOOTREST	RG80/125
51123-45420 WASHER	GSX1000, GS1150, GSX500/550/750, RG250
54451-26500 LEVER BRAKE CAM	DR2125, DS80, JR80, RM50, TS50
09289-29002 OIL SEAL R.H.	PE175, RM100/125
09160-16018 WASHER	PV50
09160-14046 WASHER GEAR SHIFT	DR400, DR2400, DS80, FL125, GD110, JR80, PV50
12140-46130 RING SET PISTON	PV50, TS50
09280-39001 O-RING	RM2250/450, RMX450
16315-35620 CAP ENG OIL FILTER OUTER	RMZ450
13503-37100 SPRING	DR250, GN250, SP400, TU250
23111-15501 ROD CLUTCH PUSH	JL650, DR650, GSX600/650, GSXR1100/400/750, GSX1100/500/550/600/750, SFV650
17431-36F00 GASKET WATER PUMP	RM125
11483-03B00 GASKET MAGNETO COVER	RM85
11483-36E11 — " —	RM125
11238-01B30-H17 GASKET CYLINDER	RG125, RGV250, RM125/80/85, TS125/200
09164-47001 SPRING	GSF1200, GSXR1100, GSX1000, GS1150, RFG00
51358-28E30 O-RING	DR400, DR2400, RMZ250/450, RM125/250, RMX250/450

69100-24821 PISTON SET	GV1400, VS1400/750/800
09280-08012 O-RING	DR650, GSF1250/250/400/650, GSR600/750/1100/ 600/750, GSX1250F, GSX1300R, GSX1400/650F, RG600, SV1000
11483-27C00 GASKET MAGNETO	RM125
09280-23002 O-RING	RM125/250, RMX250
09280-20001 O-RING	A100, AX100/115, GP100, GS250, GSF1250F, GSX250, GSX650F, GT200, K125, PE175, RG125, RM100
36212-39C00 LENS	AJ50/60, AG100/50, AH100/75, AJ50, AN125/250/400 AY50, GSX250, UC125/150, UE125
11484-27C10 O-RING	RM125
09444-16003 SPRING	RM125/250
43537-36A00 PLATE NO2 R.H.	RG125/80
16518-49200 O-RING	GSX1000, GS1150, GSX750
09263-20088 BEARING	RH85
09262-20073 BEARING, R.H.	A100, AN250/400, AX100/115, BX120, DRZ70, FB50/70/80, FM50, FR80, GP100, RB50, RM250, TF125, TS125
02112-05107 SCREW	A100, AN125/150, DR125/250/350/500/600/750/800, FA50, FB80, FZ50, GN125
51571-17200 DUST SEAL	PV50
01550-10307 BOLT	GSXR1100/400/750, RF600, RG125, RGV250, TR50, TZ50
09159-12028 NUT	GS500, GSX250/600/750
13394-40300 CLIP NEEDLE	A100, AJ50/60, AG100/50, AH100/75, AJ50, AP50, FB100, FZ50, JR50, PV50, RC50, RG50, RMX50
12161-36E00 ROD CONNECTING	RM125
09494-00453 JET NEEDLE	RM125/250
55108-34020 BOOT PISTON	GS1000, GT200/250
12141-13A11-050 RING PISTON	RM250
01421-06203 STUD BOLT	AX115, DL1000, DRZ250, DR250/650, DS80, GSF1200/600, GSXR1100/750, GSX1100, GS1150, GSX1200/600/750, JR80, LS650
12151-15002 PIN PISTON	GS1000, RM250/465/500
11482-14303 GASKET CLUTCH COVER	DR250/350
11489-49201 GASKET OIL PAN	GSX1100, GS1150
43531-48E00 BAR, FRONT FOOTREST R.H.	VZ800
23117-46E00 COVER CLUTCH RELEASE	GSF1200, GSXR1100, GSX1200, GSX1300R, GSX1400, RF900
09283-32024 OIL SEAL R.H.	GR650
09263-20073 BEARING FRONT	DL1000/650, DRZ250, DR250/650/750/800, GSXR1000/ 600/750/1300, GSX600/750, RG125, RGV250, SFV650
11483-47000 GASKET	GS500/550
11482-05310 GASKET CLUTCH COVER	GN125
11482-22300 GASKET CLUTCH COVER	RGV250

51153-19D00	OIL SEAL	RG125, VS600/800
51152-39A40	BUSH GUIDE	VS600/800
51121-19D00	BUSH SLIDE	RG125, VS600/800
51572-38B00	COVER CASE	VS1400/600/800
36381-20A10	CASE PILOT LAMP	RG250/500
51195-36220	PIECE OIL LOCK	GN125, GP100/125, GS125, GT200/250, RG125/80, SB200, TS185
65320-02D51	SPOKE ASSY WHEEL	RM80/85
35652-02181	LENS	DR125/200/500/600/650/750/800, GSXR1100/750, RG125/250/500, RG80
04111-20208	COTTER PIN	A100, AX100/115/BX120/CS125, DF125/200, DRZ125/400, DR125/200, DR2125/400, DR125/200/250/350/400/500/600
94434-16710	NUT	RG125/250/500/80
43111-33E00	PEDAL BRAKE	GSXR600/750, SV650/TL1000
43511-19F00	BRACKET FRONT FOOTREST	SV650
09168-06121	GASKET	AP50, DR125/600/650/800
09320-14006	CUSHION	J580, GSX600/750, JR80, PV50, RH50, SP370/400, TF125, TS100/125/185/250, TS50
57184-40300	V RING	PE175/250/400, RM100
61421-14210	PLATE CHAIN ADJUSTER	PE175, RM125/250
43913-40400	SPACER CHAIN	DR250/400/500, PE175/250/400, RM100/125/250/465, RM500, TS250
43915-14101	BOLT UPPER	DR500, RM125/250/465
61421-14210	PLATE CHAIN ADJUSTER	PE175, RM125/250
43913-40400	SPACER CHAIN ROLLER UPP	DR250/400/500, PE175/250/400, RM125/250/465/500
61410-14131	ADJUSTER CHAIN	RM250/500
62316-14110	SPACER LOWER	RM125/250/500
09101-08014	BOLT REAR	DR500/125/250/465/500, TS250
95673-24A00	CAP	GV1400, VS1400
09263-15003	BEARING	CP50/80, CS50/80, DF125/200, DL1000/650, DRZ125, DR125/200/250/400, EN125, GN125/250
95672-24A00	CAP	GV1400, TR50, VS1400/600/750/800
09280-15003	O-RING	FM50, GSX1400, LS650, VL800, VS600/800, VZ800
09284-20001	SEAL REAR	RMZ250/450, RM125/250/85, RMX250
12140-38B30	RING SET PISTON	VS1400
51920-38A00	CASE	VS1400/750/800
56321-49G00	BOLT	GSF1200/1250, GSX1250F, RMZ250/450
13101-40C00	PIPE INTAKE 1	GSF1200, GSXR1100, GSX1100, GS1150
13102-40C00	PIPE INTAKE ML	— " —
13103-40C00	PIPE INTAKE 3	— " —
13104-40C00	PIPE INTAKE 4	— " —



09280-25001 O-RING	GR650, GS1000, GS F1200, GSXR1100/750, GSX1000/1100 GS1150/500/550/750, RG500, XN85
13374-35C00 O-RING	AN125, DRZ250, DR125/200/250/650, GN125, RM125, TV250, VL125/250, VS1400/800, VZ800
09283-32045 OIL SEAL	RMZ250/450, RMX450
09166-16012 LOCK WASHER	DF125, DRZ125, DR125, EN125, GN125, GS125, GZ125, RV125, TV125
61251-14100 SPACER	PE175, RM125/250/465/500, TS125/200/250
64845-14100 COVER PANEL DUST SEAL	RM125/250/465/500, TS125/250
61349-40211 PAD	PE175, RM125/250/500/80
09280-46002 O-RING	DR500/600/650, LS650
09280-42003 O-RING	AN400, GS F1200/1250/650, GSR600, GSXR600/750, GSX1200 GSX1250F, GSX1400, GSX650F, GSX750, RF600/900, VS1400
09263-22060 BEARING	RG125, RM125
09160-22077 WASHER	RM125
12161-36E12 ROD CONNECTING	RM125
62316-14501 SPACER	RM500
54750-04700 SPACER AXLE LH.	AH75, RB50, RG50, TV50
09283-25066 OIL SEAL LH.	GP100/125, PE175, TF125, TS100/125/185
51153-14D00 SEAL OIL	DL1000, DRZ250, DR350, GS F1200, GSXR750, GSX1200/750, RF900
09283-26007 OIL SEAL	AX100/125, FR80, TF125, TS100/125/185
32101-17230 STATOR ASSY	PV50
25351-30010 STOPPER CAN NO2	DF125, DRZ125, DR125/250/400, GN125/250, GS1600/1100/125/ 250/450/500/550/650/850
61341-27C00 GUIDE CHAIN	DRZ50/350, RM125/250, RMX250
37560-38A00 SWITCH ASSY CLUTCH	GN250, GS500, GS F1200/400/600, GSXR1100, GSX1200/250/ 400/600/750, RF600/900, RG125, JV650, VS1400
09283-20024 SEAL DUST	F550, FZ50, RM80/85
35652-43420 LENS	GSX1100, GS1150, GSX500/550/750
09160-09007 WASHER	PV50, VS1400
25600-36F30 LEVER ASSY GEAR SHIFT	RM125
12140-20910 RING SET PISTON	RM80
43550-31300 RUBBER FRONT FOOTREST	GSX1100, GS1150, GSX1400, VX800
44306-17C00 LEVER	GSXR1100/400/750
08316-10063 NUT	A100, AD50/60, AE50, AG100/50, AH100, AJ50, AN125/150/ 250/400, AP50, AX100/115, AZ50
57460-17C01 SWITCH ASSY STOP	ANG650, AY50, DRZ250, DR200, EN125, FL125, GS500/GSXR1000/ 600/750, GZ125/250, LS650, UN125/150, VL125
13500-31300 DIAPHRAGM	GSX750
27510-48B00 SPROCKET ENGINE 15	GSXR1100, GSX1100, RF900
21141-27C11 BOLT	RM125/250, RMX250



09261-02001 PIN	AX100, A100, AX115, AY50, DR2750, DR125, EN125, GP100, GT200, GZ125, X125, PE175, RG125, RGV250, RM100
13156-03000 GASKET REED VALVE	RG125, TS125 /200
11276-03000 GABLE ASSY EXHAUST VALVE	TS125 /200
K5220-00028 WASHER	RM2250
51158-49000 WASHER	GS1000, GSX1100, GS1150, GSX500/550
51162-70040 CIRCLIP	DR250/600/650/750/800, GS1000/1100/500/550/650/850, GSXR1100/400/750, GSX1000, GSX1100, GS1150
69691-45001 BOOT	GS1000/1100/500/550/850, GSX1000, GS1150, GSX400/500/550/750, XN85
62684-14520 COLLAR	DR500/600/650/750/800, RM125/250/500, TS250
09241-47004 PLUG COUNTERSHAFT	GSX1000, GS1150, GSX750
61262-49000 COVER, DUST SEAL	GR650, GS1000, GSXR750, GSX1100, GS1150, GSX500/550, XN85
62317-05000 SPACER, FRONT	DR2250, DR250/350, RMX250
47130-33101 KNOB FRAME LH,	GR100/125, JR50, SP370/400
12140-02540-050 RING SET PISTON	RM80
09440-11014 SPRING	DF125, DR2125, DR125, GN125, GS125, RV125
14771-03000 CONNECTOR 2ND MUFFLER	RG125, RGV250, TS125
09448-18027 SPRING R.H.	RM125
09320-09016 CUSHION	AH100/75, AN125/150/250/400/650, AP50, DL1000/650, DR2250, DR250/350/650/750/800
09140-24002 NUT	K125, TS250
09263-18014 BEARING	RM250
09106-08128 BOLT	GSF400, GSX600, VZ800
09160-19001 WASHER	A100, FR80, GP100/125, GS450, GT200/250, RM100/125, SB200, TF125, TS100, TS125
13781-04400 FILTER	JR50
08322-21056 WASHER	AE50, CP50, DR125/200/250/500/600/750/800, GR650, GS1100/450/850, GSX1100, GS1150, GSX400, GV1400
09329-10005 CUSHION FRONT	A100, GSX400, K125, PV50, RM50, TS50
09443-11039 SPRING	RM125/250, RMX250
08322-21057 WASHER	DR250/750/800, FA50, FB50/80, FM50, GP100, GS1100, GS125, GSXR1100/750, GSX1100, GS1150, GSX550/750, GV1400
09160-05013 WASHER	AP50, AX100, CS125, CS50/80, DR500/600, FS50, GN125, GP100/125, GS125/500/550, GSF1200/1250
25600-20400 LEVER GEAR SHIFTING	RM80
09280-12006 O-RING	CS50, PE175, RM125/250/465/500
62660-14103 STOPPER TENSION	PE175, RM125/250/465
62666-14101 RUBBER TENSION STOPPER	PE175, RM250/465
64339-40410 DUST SEAL	DR500/600, GSXR1100, GSXR400/750, RG500, RGV250, RM125/250/465/500, TL1000, TS125/250

26842-14A02 HOLDER NO2	DR500/600
68131-39A00-C2P EMBLEM	V5800
56200-36B10 BALANCER SET HANDLE BAR	DR650, GS125, GSXR400, RG125/80, RGV250
09284-24001 OIL SEAL	AD50/60, ALS0, AG100/50, AH100/75, AJ50, AP50, AY50, RV125, UF50, DG110, UX50
64213-14600 SPACER, PANEL	RM250/500
64712-14201 WASHER	RM125/250/465
64781-14201 SPACER CHAIN ADJUSTER	PE175, RM125/250/465/500
64741-05D00 SPACER, RH	DR250/350/650, RMx250, XF650
09448-32004 SPRING	RM50, TS50
23261-41301 PINION RELEASE	DS80, JR80, PE175, PV50, RM100/50/80, TS50, ZR50
11177-44B00 O-RING	DR750/800
09167-22012 WASHER	DR400, DRZ400, DR250/400/500, GN250, GR650, GSX400, GZ250, RM250, SP370/400, TS250, TU250, VL250
35602-08F00 LAMP ASSY FRONT TURN, LH	GSX600, GSX750
35603-14A52 LAMP ASSY REAR TURN SIGNAL	DR500/600/650, GSXR750, RG125/250/500/80
51351-38B00 CAP	VL1500, V51400
12600-44B40 CLUTCH SET STARTER	DR750/800
56210-36A11 HOLDER HANDLEBAR, RH	RG125/80
09263-20063 BEARING, CENTER	RM125/250, RMx250
09168-06023 GASKET	AN125/150/250/400/650, DF125/200, DL1000/650, DR400, DRZ125/250/400, JR125/200/250
09280-33004 O-RING	AN650, DL1000, DR400, DRZ450, DR250/350/500/650/750/ 800, GN250, GSX400, GSXR600/750/1100
61273-26C00 BUFFER CHAIN DEFENSE	RM125/250
11485-44B00 GASKET GEAR SHIFT COVER	DR750/800
51167-01D00 METAL SLIDE	GS500, GSX250, GW250, VL125/250
51121-49200 SLIDE METAL	GS1100/850, GSX1100, GS1150, GSXR750